

## ASSEMBLY INSTRUCTIONS FOR MODEL 8E32 AZURE MODERN BED



**1**  
Locate headboard and side rail marked with **R**.  
Ensure bolts are present and bolt heads are backed out approximately 1/2".



**2**  
On right side of headboard, with **R** nearest to headboard, lift and position siderail bracket slots over bolt heads and lower into position.



**3**  
Locate siderail marked with **L** on left siderail and repeat process used for installing the right siderail onto headboard.



**4**  
Bring footboard into position and attach both footboard siderail brackets using the same technique as used for installing headboard.

## ASSEMBLY INSTRUCTIONS FOR MODEL 8E32 AZURE MODERN BED



Tighten all eight bolts using 1/2" wrench or socket. Tighten snugly, but there is no need to over-tighten.



Simply place the ends of the bed slats into the dovetail brackets on the siderails.



Bed will now appear as this. Slats are hold in position by dovetail brackets and are secure this way.



Place platform panels in this manner. Headboard, footboard and siderails will ensure location of panels.

## ASSEMBLY INSTRUCTIONS FOR MODEL 8E32 AZURE MODERN BED



The panels are placed over the slats to provide maximum stability and ensure rock-solid support. There is no fastening required.

Bed is now fully assembled and ready for your mattress to be installed.